


Step 1

Unload and check the firearm to be unloaded by physically and visually inspecting the firearm. Ensure that all ammunition has been removed and the chamber is empty.

 **Always** personally verify that all ammunition has been removed before training. Do not allow any live ammunition in the training area.

Warning - firearms can cause serious injuries or death.

Step 2

- Unscrew the laser bullet and insert the battery pack into the laser bullet according to the drawing.
- Reassemble the laser bullet carefully



Step 3

- Retract the action/slide and engage the slide stop in the open position.
- Make sure the action/slide is held firmly by the stop.
- Do not continue if the slide is not held firmly or the slide stop is not in good working order.



Step 4

- While pointing the barrel down, insert the Laser bullet into the handgun by “dropping” it, laser first, through the slide opening into the chamber.



Step 5

- Press gently on the back of the Laser Bullet with your finger.
- Carefully insert the Safety Pipe's thin threaded end into the barrel.
- Screw the Safety Pipe into the Laser Bullet until you feel **mild** resistance.



Step 6

- For a barrel longer than 4.5' (11.4mm), connect the pipe extension to the safety pipe by threading them together tightly.
- If needed, additional extensions are available from Laser Ammo.



Step 7

- Screw the safety nut onto the pipe, and turn the nut until it meets the barrel and you feel **mild** resistance.



Step 8

- Release the slide stop.
- Point the weapon at a safe backstop and pull the trigger to test that the unit is properly installed and functioning.



Disassembly:

- Remove the magazine if in place.
- Retract the action/slide and engage the slide stop as in Step 3 of the assembly procedure.
- Press gently on the back of the laser bullet with your finger and unscrew the Safety Nut from the pipe.
- Unscrew the Safety Pipe and remove from the barrel.
- Point the barrel up, while positioning your hand, palm upward, under the magazine well.
- If necessary, shake the weapon, and the laser bullet will slide out through the magazine well.

Maintenance:

The laser bullet is an electronic device and should always be treated as such.

- Store in original case.
- Wipe the laser bullet only with a soft fabric - do not immerse in solvents or cleaning agents.
- Clean the laser lens using a glass cleaner and cotton swab.

Warranties:

Laser ammo warrants that the products shall be free from material defects and defects in workmanship for the early of a period of one (1) year or 5000 Laser "shots" from the date of purchaser's receipt of the products. Notice of any warranty claim must be received by Laser ammo, in writing, prior to the expiration of the warranty period. Laser ammo's warranty is limited solely to the above and applies only for the period set forth.

Laser ammo will not be liable for any loss, damage, direct, incidental or consequential damages of any kind, whether based upon warranty, contract, negligence, or strict liability, or arising in connection with the sale or use of the products by the user or any third party.

Laser ammo's warranty does not cover any damage to products that result from improper installation, accident, abuse, misuse, natural disaster, insufficient or excessive electrical supply, abnormal mechanical or environmental conditions, or any unauthorized disassembly, repair, or modification.

This limited warranty also does not apply to any product on which the original identification information has been altered, obliterated or removed.

Laser ammo will, at its sole option, either repair or replace any part of its products that prove defective by reason of improper workmanship or materials.

In all events, Laser ammo's maximum liability to purchaser related to any warranty claim or defect with respect to the products shall not exceed the contract price for the specific products claimed to be defective or unsuitable, or alleged to have been the cause of any damage to purchaser or any third party. The foregoing is in lieu of all other warranties, oral, expressed or implied, including, but not limited to, any implied warranties of fitness for a particular purpose. The provisions of this section shall be applicable to both implied warranties (if any) and expressed warranties.